

# Plain English Guide to using your timers

If you live in West Alness and have had gas central heating installed in the last 10 years you are likely to have a digital timer which looks like this



This guide can be followed to change this timer. Actions are underlined. *Explanations are in italics.*

## To change the time

1. Press PROG button – *Display time and day will flash*
2. Press + and – buttons *until display reads the correct time.*
3. Press DAY button *until display reads the correct day.*
4. Press PROG button 3 more times *until display returns to normal.*

## Red SELECT buttons

There are two of these, one for the central heating (CH) and one for hot water (HW). CH and HW do not need to be set at the same times.

ON	CH or HW will be on permanently
OFF	CH or HW will be off permanently
AUTO	CH or HW will come on and off at 3 different times in the day (On at time1, Off at time2, etc)
ALLDAY	CH or HW will come on at time 1 and off at time 6 ignoring what 2, 3, 4 and 5 are set at.

## To change your central heating settings to Auto

*6 times to be entered:*

*1,2 = period one on and off*  
*3,4 = period two on and off*  
*5,6 = period three on and off*

*If you for example you do not want CH on in the middle of the day set times 3 and 4 to be the same.*

1. Press PROG twice *Display will show SET CH along the top with an 'ON' flashing. Underneath will be a number 1 on left hand side with the time your heating will first come on displayed in the centre. To change this press the + or – buttons.*
2. Press NEXT ON/OFF *Display will show an 'OFF' flashing on top line, underneath it, a 2 on the left hand side with the time your heating is set to come off. Again change this by pressing + or – buttons.*

3. Press NEXT ON/OFF *Display will have an 'ON' flashing, a no. 3 and a time. This is the time your heating comes on for the 2<sup>nd</sup> period in the day. Change using +/- buttons.*
4. Press NEXT ON/OFF *Display will have an 'OFF' flashing, a no. 4 and a time. This is the time your heating goes off for the 2<sup>nd</sup> period in the day. Change using +/- buttons.*
5. Press NEXT ON/OFF *Display will have an 'ON' flashing, a no. 5 and a time. Set this to the time you want your heating to come on in the evening by using the +/- buttons.*
6. Press NEXT ON/OFF *Display will have an 'OFF' flashing, a no.6 and a time. Set this to the time you want your heating to go off before you go to bed using the +/- buttons.*
7. Press PROG twice *Display will return to the normal screen.*

### **To change your hot water settings to Auto**

1. Press PROG 3 times *Display will show HW for Hot Water on top line with an 'ON' flashing. Underneath will be a 1 on the left hand side and the time displaying when your hot water will come on first in the morning. Change this using the +/- buttons.*
2. Follow steps 2-6 from above *This will set the 3 periods your hot water will come on during the day.*
3. Press PROG once *Display will return to normal screen*